



COVERAGE  
750 ml = ± 7 m<sup>2</sup>

DRYING TIME

2 hours  
before paint

**EASY**  
to apply

**INCREASES**  
FLOORING  
POROSITY

Formats : 750 ml

## EASY, FAST, EFFICIENT!

- Gives partially worn timber a uniform appearance without the need to sand or Strip
- Prevents the formation of rust marks caused by nails
- Blocks stains in the wood
- White and other shades maintain their colour on high-tannin woods such as oak and chestnut

# Preparation Wooden Floors & Stairs



## STEPS FOR A SUCCESSFUL PROJECT

This product is designed for untreated, painted or varnished interior wooden flooring. Not suitable for exterior, oiled or waxed timber.

Surface PREPARATION is ESSENTIAL. See Step 1 below

WASHING the surface with a soda-based (alkaline) cleaner is essential. Greasy or plastic-coated materials can stop the paint from sticking

### > STEP 1 - PREPARATION

If necessary

- > Remove any residual carpet glue.
- > Remove any silicone sealant which will need to be reapplied after painting.
- > Wash any greasy or soiled surfaces with a soda-based (alkaline) cleaner.
- > Treat any infested wood.
- > Fill any gaps or cracks.

Rinse thoroughly to remove all traces of cleaning product and leave to dry.

Lightly sand the entire surface you're going to paint. Sanding the surface back to bare wood isn't necessary, but light sanding with a fine grade abrasive is ESSENTIAL (this will form a fine dust).

*Always carefully vacuum the surface and adjoining walls or skirting boards before applying any product.*

### > STEP 2 - APPLICATION

#### Tools:

Wide stick • Brush for acrylic paint • Long-pile roller (8 to 12mm) • Fine grade abrasive (150)

Before applying the product, mix with a wide stick. This is a clear, ready-to-use product, do not dilute. One coat is sufficient.

1. Apply the preparation product in regular, criss-cross strokes and avoid excessive build-up.  
On flooring: start at the edges of the room with a brush, and then continue with a roller. Finish in the direction of the floorboards. Work in small areas of 2m<sup>2</sup> at a time.  
On stairs: start at the top of the stairs, applying the product to the steps and risers. It can be applied to the centre of the steps with a small roller. Then apply to the stair stringer, bannisters, etc.
2. Leave to dry for 1 to 2 hours.
3. If the grain of the wood has lifted to give a rough surface, lightly sand with a fine grade abrasive when the surface is dry. Warning: do not press too hard when sanding to avoid removing too much product. If in doubt, apply a second coat, ensuring the surface is dust-free.
4. Remove all dust.
5. Apply V33 Floor & Stairs Renovation paint.

Apply the product at an ambient temperature of between 10 and 25 °C and avoid draughts. • Do not allow the product to enter and accumulate in the gaps between floor boards • Do not exceed the recommended coverage rate • Do not apply the product either too thickly or too thinly • Do not stop applying the product in the centre of a surface • Do not start reapplying the product while it's still drying • Clean your tools with water.