



ASPECT  
Satin

COVERAGE  
750 ML = ± 7m<sup>2</sup>  
2 L = 20 m<sup>2</sup>

DRYING TIME

RECOAT  
3 hours

FULLY DRY  
12 hours



Formats : 750 ml – 2L

## EASY, FAST, EFFICIENT!

- Does not flake off, follows the wood variations
- Non-drip, even on vertical surfaces such as baseboards or risers
- Resistant to impact, punctures and abrasions as a result of repeat foot traffic
- Resistant to stains and dirt
- Resistant to frequent cleaning: washable with traditional household products



# Renovation Wooden Floors & Stairs



## STEPS FOR A SUCCESSFUL PROJECT

This paint is designed for ceramic tiles, wall tiles, border tiles, etc. Not suitable for flooring, shower trays, bathtubs, sinks and work surfaces.

Surface PREPARATION is ESSENTIAL. See Step 1 below

Optimum product performance and adhesion is achieved after 15 days from application. Treat the surface gently, avoiding direct impact, abrasion, staining or cleaning, for the first 15 days after application

### > STEP 1 - PREPARATION

- On LAMINATES: wash, rinse with water, leave to dry, then lightly sand (240 grit) and remove dust.
- On FLOORING, WOODEN PANELS, etc:  
Untreated timber: lightly sand and remove dust.  
Previously varnished or painted:  
> In good condition: wash, rinse with water, leave to dry, then lightly sand (150 grit) and remove dust.  
> Partially worn: sand back to bare wood and remove dust or apply the V33 Preparation for Floors & Stairs.

• Treat any infestation or insect damage • Refill joints, cracks or fissures • Greasy or plastic-coated materials can affect the adhesion of the paint • WASHING the surface with a soda-based (alkaline) cleaner is essential • Always carefully vacuum the surface and adjoining walls or skirting boards before applying any product.

### > STEP 2 - APPLICATION

#### TOOLS :

Wide stick • Brush for acrylic paint • Long-pile roller (8 to 12mm) • Fine grade abrasive (150).

Before applying, stir the paint with a mixer or wide stick, working around the bottom of the tin to mix it well. Ready-to-use product, do not dilute.

1. Apply the preparation product in regular, criss-cross strokes and avoid excessive build-up.  
On flooring: start at the edges of the room with a brush, and then continue with a roller. Finish in the direction of the floorboards. Work in small areas of 2m<sup>2</sup> at a time.  
On stairs: start at the top of the stairs, applying the product to the steps and risers. It can be applied to the centre of the steps with a small roller. Then apply to the stair stringer, bannisters, etc.
2. Leave to dry for about 3 hours.
3. Apply the second coat.

The floor can be lightly walked on after 12 hours • To obtain the optimal performance and resistance, two coats of paint are essential. For bright colours, dark or porous supports, it may be necessary to apply an additional coat • For better results with woods that are rich in tannins such as oak, we recommend you first apply the V33 Preparation for Floors and Stairs product • Apply the paint between 10 and 25 °C and avoid draughts • Do not allow the product to build up in the gaps between floor boards • Do not exceed the recommended coverage rate • Do not apply the product either too thickly or too thinly • Do not stop applying the product in the centre of a surface • Do not start reapplying the product while it's still drying • Interior use only • Remove as much paint as possible from brushes and rollers before washing. Clean your tools with water.