



ASPECT  
Satin

COVERAGE  
500 ml = ± 6 m<sup>2</sup>

DRYING TIME  
RECOAT  
12 hours

FULLY DRY  
24 hours



Format : 500 ml

## EASY, FAST, EFFICIENT!

- Smooth finish
- Resistant to frequent cleaning
- Resistant to stains & impact
- Washable

5021810

White  
SATIN

5021813

Carbon  
SATIN

5021792

Midnight Black  
SATIN

5021807

Chilli Red  
SATIN

5021808

Cassis  
SATIN

# Renovation Household Appliances



## STEPS FOR A SUCCESSFUL PROJECT

This paint is designed for fridges, dishwashers and other aluminium, metal or plastic goods. It is NOT suitable for use on sealants, or high-heat goods such as ovens, microwaves, toasters etc.

Surface PREPARATION is ESSENTIAL. See Step 1 below.

Optimum product performance and adhesion are achieved after 20 days from application. Treat the surface gently, avoiding direct impact, abrasion, staining or cleaning, for the first 20 days after application.

### > STEP 1 - PREPARATION

**ALUMINIUM, METAL, STAINLESS STEEL:**  
degrease with acetone then allow to dry.

**SMALL PLASTIC SURFACES:**  
wash, rinse thoroughly with water, allow to dry. Lightly sand (240 grit) and remove dust.

**WASHING the surface with a soda-based (alkaline) cleaner is essential.**  
Greasy or plastic-coated surfaces can affect the adhesion of the paint.

### > STEP 2 - APPLICATION

#### Tools

Paint mixer or wide stick • Paint roller & brush (for angles, corners, joints & finishes)  
Before applying, stir the paint with a mixer or wide stick, working around the bottom of the tin to mix it well.  
This is a ready-to-use product, do not dilute.

1. Start by painting the angles, corners and joints of the surface with a brush.
2. Distribute the paint evenly on a roller and apply the paint with vertical strokes. Follow with successive horizontal strokes, perpendicular to those just applied.
3. Finish with further vertical strokes for perfect results.

To achieve the best results in terms of performance and resistance, two coats of paint are essential.  
Touch dry: 2 hours - Recoat: 12 hours - Fully dry: 24 hours. For bright colours, dark or porous surfaces, it may be necessary to apply an additional coat.

Interior use only • Before applying the paint, cover any areas of the surface or surroundings that are not being painted  
• Work on small surfaces (0.5-1m<sup>2</sup>) • Do not exceed the recommended coverage rate • Do not apply the product either too thickly or too thinly • Apply the paint between 12 and 25 °C and avoid draughts • Do not stop applying the product in the centre of a surface • Do not start reapplying the product while it's still drying • Remove as much paint as possible from brushes and rollers before washing. Clean your tools with water • To clean painted surfaces, use a gentle detergent.  
Do not use abrasive sponges