

Formats: 750ml - 2L

EASY, FAST, EFFICIENT!

- Adheres perfectly to smooth and sealed surfaces
- Resistant to direct impact and stains
- Resistant to repeated water contact
- Resistant to frequent cleaning
- Washable











Renovation Panelling



STEPS FOR A SUCCESSFUL PROJECT

This paint is designed for PVC panelling and varnished, painted or untreated wooden panelling/woodwork. Not suitable for flooring or waxed or oiled surfaces.

Surface PREPARATION is ESSENTIAL. See Step 1 below

Optimum product performance and adhesion is achieved after 20 days from application. Treat the surface gently, avoiding direct impact, abrasion, staining or cleaning, for the first 20 days after application.

> STEP 1 - PREPARATION

- PVC, VARNISHED WOOD, PAINTED WOOD: wash, rinse thoroughly with water, leave to dry, then lightly sand (240 grit) and remove dust.
- UNTREATED/POROUS WOOD : remove dust then apply a conventional undercoat appropriate to the surface before applying Panelling Renovation paint.

WASHING the surface with a soda-based (alkaline) cleaner is essential. Grease or plastic-coated materials can affect the adhesion of the paint.

> STEP 2 - APPLICATION

TOOLS:

Paint mixer or wide stick • 9-12mm pile paint roller (for wood) or brush •Round-edged brush (for angles, corners, joints and finishes)

Before applying, stir the paint with a mixer or wide stick, working around the bottom of the tin to mix it well. Ready-to-use product, do not dilute.

- 1. Start by painting the angles, corners and grooves of your first painting surface.
- 2. Distribute the paint evenly on your roller and apply from top to bottom. Follow with successive perpendicular strokes (moving from left to right).
- 3. Finish from top to bottom for perfect results.

To obtain the optimum product performance and resistance, two coats of paint are essential (Touch dry: 2 hours - Recoat: 12 hours - Fully dry: 24 hours).

For bright colours, dark or porous supports, it may be necessary to apply an additional coat.

Interior use only • Work on small surfaces (about 1m2) • Do not exceed the recommended coverage rate • Do not apply the product either too thickly or too thinly • Apply the paint between 12 and 25 °C and avoid draughts • Do not stop applying the product in the centre of your surface • Do not start reapplying the product while it's still drying • Remove as much paint as possible from brushes and rollers before washing. Clean your tools with water • To clean painted surfaces, use a gentle detergent. Do not use abrasive sponges